



Tips For Filling Gaps With Polymeric Sand



Begin the process when the weather is dry and sunny for at least two days.

Ensure to dry the work area thoroughly before applying the polymeric sand.



Use the sand only to fill gaps that are one-inch deep and 1/8th of an inch to 4 inches wide.

Utilize a push broom to spread the sand in the gaps evenly.



Tap the pavers with the back of the broom to ensure the gap is completely filled.

Leave a 1/8-inch gap between the top of the paver and the sand layer to prevent overfilling.



Remove excess sand with a leaf blower to prevent a hazy or textured surface.

Avoid underwatering or over-watering the sand to secure a proper bond.



Refrain from walking or driving on the pavement for 48 hours after sand filling.

Wait for 30 days before cleaning the pavement for proper curing.

