



## Tips And Tricks To Use Shower Curtain Rods



Always clean the shower area before installing the rod.

Slide the curtain rings onto the rod before installing it.



Ensure the curtain rings are large enough to slide smoothly without getting stuck in the middle of the rod.

Use curve-type shower rods to get extra elbow space if the showering place is small.



Although shower curtains or liners aren't heavy, select rods with good weight-bearing capacity.

Opt for a rust-resistant stainless steel rod, as the shower rod is prone to moisture.



Use an adjustable tension rod if the measurement of the shower place is inaccurate or slightly larger than the standard size.

If the curtain rod slips from the tiles, use anti-slip pads to keep them in place.

