



## Tips For Cleaning

# Home Stereo Speakers



Read and adhere to the manufacturer's cleaning instructions.

Switch off and unplug the stereo system before cleaning the speakers.

Wipe the exterior parts of the speakers with a soft, lint-free, and slightly damp cloth.

Wipe the wooden parts following the direction of the wood's grain.

Avoid using paper towels as they may leave minute particles on the surface.

Detach the grill from the speaker (if applicable) before cleaning it with a lint roller.



Use a compressed air spray designed for electronic devices to dust the speaker cone gently.

Avoid water-based solutions or compressed air to clean the speaker terminals.