

Tips To Use A Computer Vacuum

Unplug the laptop or PC.




Remove the CDs or USB connections.

Place it on a static-free mat to keep it away from electrical discharge.




Put the correct attachment on the cleaner to suit your needs.

Ensure the vacuum setting is not high because the high-pressure setting may suck the keys off the keyboard.



Vacuum the exterior of the computer and the keyboard.

Avoid vacuuming internal parts of the computer or laptop.



Turn ON the laptop or plug in the PC to check if it is functioning well.