



Tips To Keep An Air Mattress From Deflating



Inflate the bed a few hours before using it to allow the material to expand.

Hold back from overfilling or underfilling the mattress.



Secure the valves snugly to deter slow leaks.

Avoid sitting on its edges or just one side to prevent leaks.



Keep pets and sharp objects away to prevent microscopic punctures.

Avoid putting more weight than the limit mentioned by the manufacturer.



Check for and patch any holes in the mattress.

Fold the mattress along the seams to keep it from fraying and leaking.



Keep the mattress deflated when it is not being used.

Store the mattress in a cool and dry place to prevent tears.

