

Steps Involved In Using Anti- Fog Solutions For Eyeglasses




Step 1: Clean your glass lenses using a soft cloth to remove dirt or debris.



Step 2: Grab the anti-fog solution bottle and shake it well.



Step 3: Apply a thin layer of the solution on both sides of the lenses.



Step 4: Wait for the prescribed time recommended by the manufacturer for it to dry.



Step 5: Use a dry and lint-free cloth to wipe the lenses.



Step 6: Use another dry and lint-free cloth to buff the lenses till clear.

